


IR-100 Remote



Learning Remote Feature

Learning methods please see as below:

- Press and hold "Power"+"OK" more than 3 seconds, the LED will be turned on, indicates the remote enters learning mode.
- Align the IR tube of the remote control with the IR tube of the remote control which needs to be learned within 3cm.
- Press the "TV Power" button on the remote control, the LED will change from long light to slow flashing, waiting to receive the learning signal. Press the button of the remote control which needs to be learned and keep it sending the IR code. When the remote controller receives the learning signal, the LED flashes 3 times and then long light, indicating that the learning signal is received.
- Repeat step c to learn "Source" key.
- Press the "OK" key, then the LED turned off, indicates the code has been save and exit the learning mode.