


BT-200 Remote



Learning Remote Feature

Learning methods please see as below:

1. Long Press the "TV Power" + "Source" keys on the RCU at the same time for 3 seconds until the Blue LED turns solid Blue.
The RCU has now entered learning mode.
2. Press the key on the RCU to be programmed, for example "TV Power" Key, the Blue LED will start blinking.
3. Aim the TV RCU that you want to learn from towards the front of the RCU (Distance less than 3cm).
Press the button on the TV RCU that you want the BT-100 RCU remote to learn from. If the BT100 RCU is programmed correctly the Blue LED on the BT-100 \ RCU will blink 3 times then turn solid Blue.
This will indicate that you have programmed it properly.
4. Repeat Steps 2-3 for the "Source" button.
5. Short press "TV Power" key + "Source" key at the same time on the BT-100 RCU to exit learning remote.