




HD5


User Manual



1 Package Contents




2 Connections



3 Installation Steps

1. Connect the HD5 to your HDMI port on your TV.
2. Plug type C power cable to HD5 and connect the Power Supply and to AC outlet.



4 Pairing the BT-400 to the HD5 and other BT devices

You can pair your HD5 to the BT-400 remote in 2 ways.

1. Depress the reset button (shown in Section 2) this will put the HD5 into the BT pairing screen and walk you through the pairing process like you did when you originally set up your HD5.
2. To add other BT accessories go into settings click on BT and click add accessory , this will put the HD5 into BT pairing mode.

5 BuzzTV Smart Remote App



NOTE¹: Requires BT-400 and an enabled device. The remote must be BT paired to the device

NOTE²: If you are not using TV source pair, do not enable max audio on device
(Found in Buzz utilities under Volume control)

From the App you will be able to control:

Auto source pair your TV to the BT-400

This allows the user to have BT-400 control the TV's Power button, Volume up and down, the TV input source. Click on the tab in the app and the app will walk you through the set up.

Control the BT-400 Backlight

Program your backlight On or Off. Click on the tab and it will take you to the setting inside the device, select remote and you will see the toggle choice. (This feature is off by default for greater battery life)

6 Troubleshooting

Warning: Under no circumstances should you try to repair the HD5 by yourself, as this will invalidate the warranty. Do not open it as there is a risk electrical shock. If any fault occurs, please first check with this troubleshooting checklist. If you are unable to remedy a problem by following this guide, contact your dealer for help.

Problem	Solution
No Power	<ul style="list-style-type: none"> • Check if the power adaptor is properly connected to the power and the TV box • Press the power on the remote controller to turn on the power
No Picture	<ul style="list-style-type: none"> • Re-Connect the HD5 • Check if the HD5 and TV are powered on
No sound or distorted sound	<ul style="list-style-type: none"> • Adjust the volume • Check that the speakers are connected correctly
The TV box does not respond to the remote control	<ul style="list-style-type: none"> • You may have lost BT pairing, press reset and attempt to repair Remote after checking batteries are Ok. • Reduce the distance to the TV box • Replace batteries in the remote control • Possibility of system crash, disconnect and reconnect the power supply
No sound during playback	<ul style="list-style-type: none"> • The audio codec may not be supported by the HD5 • Check the volume
The contents of the USB or flash drive cannot be read	<ul style="list-style-type: none"> • The USB or flash drive format is not compatible with the box • If one of the drives can not be read, please turn off the unplug the HD5 for 30 seconds, then re-plug the HD5 into the TV HDMI port
Slow operation of the USB flash drive	<ul style="list-style-type: none"> • Large file size or high resolution USB flash drive takes longer time to read and display on the TV screen

7 Warranty Information

For warranty information and registration, please visit: www.buzztv.com/register

www.buzztv.com/support
cs@buzztv.com