



3 Installation Steps

1. Connect X5 AI Series TV Box to the power supply.

2. Connect X5 to your TV with an HDMI Cable or AV Cable.

 For a wired connection, plug-in an Ethernet cable from the TV Box to your modem or router. For wireless, choose your Wi-Fi network and input your Wi-Fi password.
 LED Light: Blue ON Red OFF

Troubleshooting

Warning: Under no circumstances should you try to repair the X5 Al Series by yourself, as this will invalidate the warranty. Do not open it as there is a risk electrical shock. If any fault occurs, please first check with this troubleshooting checklist. If you are unable to remedy a problem by following this guide, contact your dealer for help.

Problem	Solution
No Power	Check if the power adapter is properly connected to the power and the TV box Press the power on the remote controller to turn on the power
No Picture	Re-Connect the HDTV cable or AV cable Check if the TV is powered on
No sound or distored sound	Adjust the volume Check that the speakers are connected correctly
The TV box does not respond to the remote control	Aim the remote control directly at the sensor on thefront of the TV box Reduce the distance to the TV box Replace batteries in the remote control Possibility of system crash, disconnect and reconnect the power supply
No sound during playback	The audio codec may not be supported by the TV box Check the volume
The contents of the USB or flash drive cannot be read	 The USB or flash drive format is not compatable with the box If one of the USB can not be read, please turn off the TV box for 30 seconds and restart the TV box
Slow operation of the USB flash drive	 Large file size or high resolution USB flash drive takes longer time to read and display on the TV screen
The TV screen is blank and the player LED is blinking	 Turn off the TV box, wait 30 seconds and turn on again Check if HDTV connection is correct or try changing the HDTV cable

